






FRITZ!Box 6690 Wi-Fi 6

- Do internetového prohlížeče zadáme adresu <https://fritz.box>
- Heslo zadáme to, které je uvedeno **na štítku** ve spodní části modemu, FRITZ!Box password a klikněte na tlačítko „Log in“.



- Administrace modemu nepodporuje CZ jazyk.

- Po přihlášení nám naskočí úvodní obrazovka.

FRITZ!Box 6690 Cable

Model: FRITZ!Box 6690 Cable
Current power consumption: 28 %

FRITZ!OS: 7.57 -Version up to date

Connections and Interfaces

- Internet: not connected
- Cable: connected
- LAN: not connected
- USB: not connected
- Wi-Fi: on, Wi-Fi network (2,4/5 GHz): FRITZ!Box 6690 BC
- Telephony: No telephone numbers configured
- DECT: off

Calls today: 0 At a Glance Daily with MyFRITZ!

No calls
To Call List To the Answering Machine

Home Network Devices enabled: 1 To Overview Diagram

- E1517855 Wi-Fi - 5-GHz

Convenience Features

- Answering Machine: disabled
- Telephone Book: 1 telephone book found
- Storage (NAS): 188 MB used, 2,9 GB free

- Pro změnu nastavení Wi-Fi kanálů rozklikneme v levém sloupečku možnost **Wi-Fi**.
- Poté zvolíme možnost **Wi-Fi Channel**.

FRITZ!Box 6690 Cable

Wi-Fi > Wi-Fi Network

This page shows you the most important information about the Wi-Fi network of your FRITZ!Box. In addition to the access information for your Wi-Fi network, you also find the QR code to use for convenient Wi-Fi connections to your FRITZ!Box. You also receive an overview of which devices are connected with your FRITZ!Box and can configure settings for these devices.

Name of the Wi-Fi network (SSID) FRITZ!Box 6690 **Wi-Fi network key** [Redacted] **Wi-Fi Access** [QR Code]

Additional Settings for the Wi-Fi Network

- ☐ Different naming of the Wi-Fi networks on 2.4 and 5 GHz

Start WPS **Print Info Sheet**

Known Wireless Devices in the Wi-Fi Network

The list shows the wireless devices which are currently connected with the FRITZ!Box or known from previous connections.

Signal	Name	IP address	Band	Throughput (Mbit/s)	Properties
Home Network FRITZ!Box 6690					
[Signal]	[Redacted]	[Redacted]	5 GHz	+573 +6	Wi-Fi 6, 160 MHz, WPA2, 2 x 2, 11k, 11v, MU-M...
Unconnected Devices					
[Signal]	[Redacted]	-		+0 +0	not connected

Clean Up Table? **Remove Unconnected Devices** **Refresh**

You can remove wireless devices from the overview for which no individual setting was made in the FRITZ!Box and which are currently not connected with the FRITZ!Box.

Apply **Discard**