




FRITZ!Box 6690 Wi-Fi 6

- Enter the address in the internet browser <https://fritz.box>
- Enter the password shown **on the label** at the bottom of the modem, FRITZ!Box password and click the button „Log in“.



Welcome to your FRITZ!Box 6690 Cable

FRITZ!Box

[Log In](#)

Note:
The FRITZ!Box user interface is protected with an individual password ex works. This password is printed on the sticker on your FRITZ!Box.

[Forgot your password?](#)

- Modem administration does not support the CZ language.

- After logging in, the initial screen will appear.

- To change the Wi-Fi channel settings, click on the **Wi-Fi** option in the left column.
- Then select the **Wi-Fi Channel** option.