


Comtrend WR-5804


Changing the Wi-Fi password and name in the modem administration

- **Enter the address into the internet browser 192.168.1.1 .**




- Enter the username and password from the bottom label on the modem..






- The modem's main page will appear.



- On the main page, select the **Advanced settings (Pokročilá nastavení)** option from the top bar.
- Next, select the **Wireless Network (Bezdrátová síť)** option in the left column, followed by the **SSID** option.



- Here we can set the Wi-Fi name and password..

Wi-Fi Name (SSID) Splitting

- To split the Wi-Fi name, select the **Advanced (Pokročilý)** option in the left column.
- In the table, switch the **BandSteering Daemon** to **Disabled** and set it to **Use**.

