



## LTE modem Huawei B2368 – 66 – Wi-Fi Settings




- The Wi-Fi settings are made in the modem interface.
- We recommend that you set up Wi-Fi using a connected computer with a LAN cable.
- We will open a web browser to set up. (Google Chrome is recommended)


- Let's open a web browser and type:
- [192.168.1.1](https://192.168.1.1)

← → ↻ ↱

- The link will redirect us to the home page.
- Enter the username and password from the modem label.



- This brings us to the router interface.
- We then enter Network settings and select which Wi-Fi we want to configure.





- Here we set according to our needs.
- After that, let's use it and try to connect to Wi-Fi.

- The blue arrows show the possibility of changing channels.



If you forget the passwords at any time, you can either change the passwords in this setting or reset the router to factory settings. After that, the values are back to their original settings, as indicated on the modem label.