


Remote control

Buttons description

1. Power on/off
2. Dial
3. Menu
4. Directional arrows ↓/↑/→/←
5. OK
6. Search (for the premium set-top box, there is "Voice search" and a microphone icon)
7. Back
8. Leave
9. A button to switch channels gradually
10. Adjusting the volume
11. Mute
12. Record
13. Buttons for rewinding and pausing (recording, rewind or live broadcast)
14. Button to start previous/next program (recordings)
15. "Vodafone Kids" child mode launch button
16. Program guide (EPG)
17. Netflix
18. Prime Video
19. HBO MAX



Pairing the remote control

1. Prepare the remote control for the set-top box, turn on your television and the Vodafone TV set-top box.
In order for everything to go smoothly, first turn on all the devices.
2. **Hold down the yellow button and the OK button at the same time until the green light around the power button on the remote control flashes twice.**
You can release the pair of buttons as soon as it flashes green.
3. Point the remote at your TV and **hold the on/off button until the TV turns off. It is important to hold down the power button continuously.** The button is on the remote control at the very top above the number 2. You can **release it once the TV is off.**
4. **Try using the remote control for the set-top box to turn on the TV.** If it turns on, everything is set correctly.
If the TV does not respond to the commands of the remote control, **repeat** the entire procedure.

Unpairing the remote control

1. Prepare the remote control for the set-top box, **turn on** your television and the Vodafone TV set-top box.
Hold down the blue button and the menu (house) button at the same time until the green light around the power button on the remote control **flashes twice**.
Once the green flash occurs, you can **release** the pair of buttons.
2. **Press the number 9 four times in a row**. The LED light on the controller **should flash with each press**, after the **fourth press it will flash red 4 times** to confirm that the **pairing has been canceled**.
And that's it - the pairing of the remote control to the set-top box and your TV has been cancelled.

Pairing the controller with your TV works in most cases without problems, however please understand that we cannot guarantee that this function will be available for all TVs.