




Vodafone Station (Arris TG3442DE)

Changing the WiFi name and password

- Enter the address in the internet browser 192.168.0.1 .
- You can switch the settings to Czech at the bottom of the page.
- Enter admin as the username. Enter the password indicated **on the label** on the back of the modem and click the "Login" button.



Here are two options to change Wi-Fi name and password. The first option is to have the same name and password for both 2.4GHz and 5GHz Wi-Fi. In this case, which one you are connected to is determined by which network your device is capable of (mobile phone, laptop, TV...). The second option is to have a different name and password for each network separately. In this case, you have the option to choose which frequency to connect to if your device supports it

Same SSID and Password for both networks


- In the top menu, select the **Wi-Fi** option.



- On this page we can change the network name (SSID) and the password for both networks at the same time.
- Confirm the change by clicking the **Confirm** button. The change will take place within 3 minutes at most.

A different name for 2.4GHz and 5GHz

- In the upper right corner, click on the **Basic mode** roller and switch to **Expert mode**.



- In the top bar, select **Wi-Fi** and then click on **General** in the left menu.
- Here you need to activate the option **Split SSID**.



- Now we go to the page below, and here we can already set the name for the 2.4GHz and 5GHz network separately.

Main Wi-Fi (2,4 GHz)	Main Wi-Fi (5 GHz)
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Wi-Fi Name (SSID) UPC240539897	Wi-Fi Name (SSID) Tristram
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Protection Mode WPA2	Protection Mode WPA2
Wi-Fi Password *****	Wi-Fi Password *****
<input type="checkbox"/> Display Characters	<input type="checkbox"/> Display Characters
<input type="button" value="Change Password"/>	<input type="button" value="Change Password"/>

- For each change, you need to click **Change password** separately.
- Once all changes are entered, we confirm them at the bottom of the page by clicking the **Confirm** button.
- The change will take place within 3 minutes at most

The troubleshooting procedure did not help?



- In case of non-functionality even after performing the fixed internet troubleshooting procedures, you need to contact our technical support by calling or using the Tobi chatbot, which you can find on our website www.vodafone.cz.